

interatletika™

PRODUCTION AND SALE OF CHILDREN'S AND OUTDOOR
EQUIPMENT

Customer support:


+38 095 273 81 53

play.interatletika.com

✉ export.team@interatletika.com

Park equipment of the series LP7xx, LP79x

DATA SHEET



CONTENT

| | |
|---|----------|
| 1. GENERAL INFORMATION | 3 |
| 2. TECHNICAL DATA | 3 |
| 3. COMPLETENESS | 4 |
| 4. CERTIFICATE OF ACCEPTANCE, PACKAGING AND CONSERVATION | 4 |
| 5. INFORMATION ABOUT STORAGE, TRANSPORTATION AND RECYCLING | 4 |
| 6. INSPECTION AND CHECKING | 4 |
| 7. MAINTENANCE | 5 |
| 8. REPAIR AND FAULT RECORDING | 5 |
| 9. INSTRUCTIONS FOR SAFE USE | 6 |
| 10. INSTALLATION INSTRUCTIONS | 6 |

FOR NOTES

[illegible]

1. GENERAL INFORMATION

1.1 Item number _____.

1.2 Name _____.

1.3 Manufacturer LLC«Company Sporttehnika», Ukraine, city of Chernihiv, Ushynsky St., 24.

1.4 Serial number and production date: _____, «____» _____ 20__ year.

1.5 Produced in accordance with regulatory documents: TC AT 28.9-31597759-001:2012.

The manufacturer can make changes to the product design to improve its performance, change the design, etc.

This document may not contain a description of such changes, but applies to the following modified products.

2. TECHNICAL DATA

| № | Product code | Name | Length, mm | Width, mm | Height, mm | Weight, kg |
|----|--------------|-----------------------------------|------------|-----------|------------|------------|
| 1 | LP700 | Set of embedment for concreting | 60 | 60 | 262 | 1,5 |
| 2 | LP700.1 | Embedded for installation in soil | 625 | 583 | 200 | 7,3 |
| 3 | LP700-T | Stencil for installing the slats | 405 | 130 | 15 | 0,3 |
| 4 | LP701.1 | Bench Prague | 1906 | 368 | 638 | 32,0 |
| 5 | LP701.2 | Bench Brno | 1906 | 368 | 638 | 35,6 |
| 6 | LP702.1 | Bench Munich | 1800 | 643 | 450 | 41,8 |
| 7 | LP703.1 | Bench Lisbon | 1943 | 430 | 460 | 45,4 |
| 8 | LP704.1 | Bench Oslo | 1800 | 524 | 674 | 38,1 |
| 9 | LP705.1 | Bench Dublin | 1800 | 415 | 450 | 35,2 |
| 10 | LP705.2 | Bench Belfast | 1800 | 405 | 450 | 33,3 |
| 11 | LP706 | Bench London | 1800 | 607 | 824 | 61,7 |
| 12 | LP707 | Bench Warsaw | 1800 | 655 | 824 | 65,5 |
| 13 | LP708 | Bench Naples | 1895 | 608 | 786 | 54,0 |
| 14 | LPS709 | Table with benches Copenhagen | 1800 | 1682 | 750 | 106,8 |
| 15 | LP710 | Bench Vilnius | 1950 | 562 | 767 | 55,2 |
| 16 | LPS721 | Table Bilbao | 1890 | 740 | 750 | 65,1 |
| 17 | LP721.1 | Bench Bilbao | 1890 | 390 | 450 | 37,0 |
| 18 | LP721.1-3,3 | Bench Bilbao double | 3340 | 390 | 450 | 64,4 |
| 19 | LP722 | Bench Madrid | 1800 | 494 | 849 | 50,5 |
| 20 | LPS722 | Table Madrid | 1800 | 690 | 750 | 54,3 |
| 21 | LP722.1 | Bench Madrid | 1800 | 410 | 450 | 33,8 |
| 22 | LP723 | Bench Valencia | 1890 | 634 | 825 | 53,1 |
| 23 | LP724 | Bench Seville | 1810 | 430 | 690 | 40,5 |
| 24 | LP725.1 | Bench Granada | 1886 | 544 | 554 | 43,8 |
| 25 | LP726.1 | Bench Cadiz | 1780 | 450 | 420 | 40,7 |
| 26 | LP727.1 | Bench Malaga | 2026 | 410 | 450 | 38,8 |
| 27 | LP728.1 | Bench Saragosa | 1800 | 440 | 450 | 40,5 |
| 28 | LP728.1B | Bench Salamanca | 1800 | 440 | 450 | 45,4 |
| 29 | LP729 | Bench La Coruna | 1930 | 567 | 769 | 47,8 |
| 30 | LP730.1 | Bench Cordoba | 1800 | 440 | 450 | 38,9 |
| 31 | LP731 | Bench Girona | 1800 | 524 | 850 | 61,2 |
| 32 | LP731.1 | Bench Girona | 1800 | 456 | 450 | 43,4 |
| 33 | LP732 | Bench Vigo | 1930 | 719 | 829 | 59,0 |
| 34 | LP733.1 | Bench Barcelona | 1800 | 500 | 516 | 36,9 |
| 35 | LP734 | Bench Toledo | 1930 | 513 | 809 | 43,7 |
| 36 | LP734.1 | Bench Toledo | 1930 | 410 | 450 | 32,4 |
| 37 | LP735 | Bench Alicante | 1930 | 630 | 829 | 57,5 |
| 38 | LP736.1 | Bench Almeria | 1900 | 440 | 450 | 40,7 |
| 39 | LP737.1 | Bench Albacete | 1800 | 390 | 450 | 37,3 |
| 40 | LP738 | Bench Cartagena | 1800 | 617 | 849 | 49,4 |
| 41 | LP738.1 | Bench Cartagena | 1800 | 612 | 570 | 36,2 |
| 42 | LP739.1 | Bench Merida | 2008 | 394 | 450 | 44,0 |
| 43 | LP739.2 | Bench Carmonite | 2010 | 410 | 450 | 40,2 |
| 44 | LP751.1 | Bench Monaco | 1800 | 440 | 450 | 45,2 |
| 45 | LP752 | Bench Marseille | 1800 | 670 | 847 | 68,9 |
| 46 | LP753 | Bench Lyon | 2000 | 660 | 824 | 78,5 |
| 47 | LP754 | Bench Lille | 2010 | 645 | 784 | 67,9 |
| 48 | LP754.2 | Bench Montpellier | 2000 | 645 | 824 | 69,1 |
| 49 | LP755.1 | Bench Paris | 1800 | 440 | 450 | 47,8 |

| | | | | | | |
|----|---------|--------------------|------|------|------|-------|
| 50 | LP756.1 | Bench Toulouse | 1800 | 456 | 460 | 49,5 |
| 51 | LP791 | Swing-sofa Boston | 2600 | 1040 | 2206 | 270 |
| 52 | LP792 | Swing-sofa Dallas | 2500 | 1200 | 2111 | 213,8 |
| 53 | LP793 | Swing-sofa Atlanta | 2626 | 1160 | 2137 | 244,4 |

3. COMPLETENESS

Complete set of the product is given in the «Complete set information» and «Complete set of fasteners», supplied with the product.

4. CERTIFICATE OF ACCEPTANCE, PACKAGING AND CONSERVATION

Product _____, serial number _____ complies with regulatory documents TC AT 28.9-31597759-001:2012 and recognised as serviceable.

OTC mark: «_____» _____ 20__ year.

Date

Full name

P.S.

Packed by LLC «Company Sporttechnika» in accordance with the requirements of regulatory documents.

«_____» _____ 20__ year.

Date of packing

Packed by _____

Full name

Signature

Information on conservation and deconservation during operation

| Conservation date | Conservation method | Conservation period | Deconservation date | Name of the company (organisation) | Position, full name | Signature |
|-------------------|---------------------|---------------------|---------------------|------------------------------------|---------------------|-----------|
| | | | | | | |
| | | | | | | |
| | | | | | | |

5. INFORMATION ABOUT STORAGE, TRANSPORTATION AND RECYCLING

The product is transported in the manufacturer's packaging by any means of transport that ensures its safety and protection from external factors (rain, snow, sunlight, water, high humidity, etc.).

Information about transportation

| Date | | Brand, state number of the ca/trailer | Position, full name | Signature |
|-----------|---------|---------------------------------------|---------------------|-----------|
| Departure | Arrival | | | |
| | | | | |
| | | | | |
| | | | | |

Before installation, store the product in the original packaging in dry, closed rooms with natural air ventilation.

If it is necessary to transport the product to another location after use, it is recommended to use the manufacturer's packaging.

If long-term storage of the product is required, the following storage rules must be observed (the list of conditions is not complete):

- place the product in a closed dry room with natural ventilation;
- protect the product from external factors (dust, water drops, etc.) with a large plastic bag, leaving space for free air circulation;

- take other measures to preserve the appearance and characteristics of the product during storage.

When removing the product from storage and preparing for installation, follow the next recommendations:

- remove the product from the packaging material (polyethylene, cardboard, other packaging materials);
- remove dust and other contaminants from the surface of the product;
- check completeness and absence of parts damages.

Storage information

| Date | | Product storage conditions | Full name | Signature |
|----------------------|----------------------|----------------------------|-----------|-----------|
| Putting into storage | Removal from storage | | | |
| | | | | |
| | | | | |
| | | | | |

After the end of the equipment's service life, the buyer independently determines the procedure for its use. If you decide to recycle, contact the seller or specialized organizations.

The equipment does not contain harmful impurities and materials that can harm your health and is not subject to special recycling.

6. INSPECTION AND CHECKING

Before starting the operation of the product, it is visually inspected, checked: the integrity of paint coating, fasteners and structural strength.

If there are concrete support parts of the product, make sure that they are securely fixed and do not move. Check that the equipment and site are free from packaging materials, construction debris and other foreign objects.

Check the proper condition of the shock-absorbing surfaces on the playground.

7. MAINTENANCE

Timely maintenance of the product is the responsibility of the buyer (or a responsible person) and includes:

1. Daily inspection - before using the product, check its performance, visual inspection for the absence of breakdowns, damage, sharp edges on components and parts, structural integrity, strength of wooden structures and element connection points, absence of unnecessary objects on the platforms. If the product is damaged, fully or partially inoperable, or otherwise defective, it is prohibited to use the product.

2. Scheduled inspection is carried out every three months.

It involves a detailed visual and operational inspection of the operation and stability of the equipment, especially with regard to any wear.

In the process of inspection, they determine:

- cleanliness and appearance of the surface of the playground and equipment;
- maintaining distances from parts of the equipment to the surface of the playground;
- absence of protruding parts of the foundations;
- absence of defects/malfunctions of equipment elements;
- wear of moving parts;
- structural integrity of equipment.

Special attention should be paid to hidden and inaccessible parts of the equipment.

3. Annual inspection is held every 12 months to establish the overall safety level of the equipment.

In the process of visual and functional inspection it is determined:

- structural stability;
- integrity of the foundation;
- strength of units of item elements connection;
- wear of sliding surfaces and grips.

Special attention should be given to:

- assessing the impact of weather events;
- the presence of rot or corrosion;
- parts that are closed to access during the entire period of operation.

The results of the inspection, repair or replacement of equipment components must be recorded in the maintenance record sheet.

Maintenance recording

| Date and type of inspection | Name of the work done | Remarks on the technical condition | Position, full name, signature of the responsible person |
|-----------------------------|-----------------------|------------------------------------|--|
| | | | |
| | | | |
| | | | |
| | | | |

8. REPAIR AND FAULT RECORDING

Replace all defective components with parts from the manufacturer.

It is forbidden to manufacture and replace components and parts of the equipment independently.

Recording malfunctions during operation

| Date of failure of the product, its component part or structural element | Nature (external manifestation) of the fault | Corrective actions taken | Position, full name, signature of the responsible person |
|--|--|--------------------------|--|
| | | | |
| | | | |
| | | | |

Information about the repair

| Name of a component or structural element | The reason for the repair | Date | | Name of the organisation, position, full name, signature of the person who performed the repair |
|---|---------------------------|----------------|---------------|---|
| | | Put for repair | Out of repair | |
| | | | | |

| | | | | |
|--|--|--|--|--|
| | | | | |
| | | | | |

9. INSTRUCTIONS FOR SAFE USE

Before operating the product, conduct a visual inspection, check the fasteners and structural strength.

The equipment is used without constant supervision by operating personnel. In order to ensure the safe operation of the product, the owner must conduct a daily visual inspection. If malfunctions are detected during the inspection, they must be immediately eliminated, and if this is not possible, the equipment must be closed for users.

Product use:

- it is forbidden to use until the completion of its full and final installation;
- before using clear the surface from foreign objects, sharp elements, protrusions;
- it is forbidden to move the product elements which are not intended for this;

The manufacturer is not responsible for the consequences:

- poor quality and improper installation of the product;
- use of low-quality materials and inadequate qualifications of personnel during installation of the product;
- use of the product earlier than the period necessary to fix the product in the soil or other material;
- design changes to the product that caused injury;
- damage to the product due to improper storage, installation or use of the product for purposes other than those intended.

10. INSTALLATION INSTRUCTIONS

Installation of the product can be carried out by the manufacturer, service centre or other legal entities and individuals who have the necessary material and technical base and qualifications.

The product is installed on a prepared flat area, free from debris, trees and other obstacles that interfere with installation (when installed in winter, the area shall be additionally free from snow). The required size of the site is determined by the fall zone of the equipment. When installing in winter on natural ground, it is recommended to choose a site with compacted soil in the area of foundation placement.

The height difference of the prepared site should be:

- a) no more than 50 mm for natural substrates, including substrates with subsequent shock-absorbing coating.
- b) no more than 10 mm for hard substrates (asphalt, concrete), including substrates with subsequent application of a synthetic protective coating.

Before starting the installation, you must:

- study the documentation supplied with the product;
- check the completeness in accordance with the documents supplied with the product;
- remove the original packaging from the component part;
- comply with safety requirements.


To avoid cracking of the wood, for screws with a diameter of more than 4 mm, drill holes with a diameter of 0.6...0.7 mm to a depth of 0.8 of the screw's length.

WARNING! The presence and participation of children during the installation of the product is not allowed.


Install the product in stages, following the instructions in the appendix.

General view


LP700 - Set of embedment for concreting




LP700.1 - Embedded for installation in soil




LP700-T - Stencil for installing the slats




LP701.1 - Bench Prague




LP701.2 - Bench Brno




LP702.1 - Bench Munich




LP703.1 - Bench Lisbon




LP704.1 - Bench Oslo




LP705.1 - Bench Dublin




LP705.2 - Bench Belfast




LP706 - Bench London




LP707 - Bench Warsaw




LP708 - Bench Naples




LPS709 - Table with benches Copenhagen




LP710 - Bench Vilnius




LPS721 - Table Bilbao




LP721.1 - Bench Bilbao




LP721.1-3,3 - Bench Bilbao double




LP722 - Bench Madrid




LPS722 - Table Madrid




LP722.1 - Bench Madrid




LP723 - Bench Valencia




LP724 - Bench Seville




LP725.1 - Bench Granada




LP726.1 - Bench Cadiz




LP727.1 - Bench Malaga




LP728.1 - Bench Saragosa




LP728.1B - Bench Salamanca




LP729 - Bench La Coruna




LP730.1 - Bench Cordoba




LP731 - Bench Girona




LP731.1 - Bench Girona




LP732 - Bench Vigo




LP733.1 - Bench Barcelona




LP734 - Bench Toledo




LP734.1 - Bench Toledo




LP735 - Bench Alicante




LP736.1 - Bench Almeria




LP737.1 - Bench Albacete




LP738 - Bench Cartagena




LP738.1 - Bench Cartagena




LP739.1 - Bench Merida




LP739.2 - Bench Carmonite




LP751.1 - Bench Monaco




LP752 - Bench Marseille




LP753 - Bench Lyon




LP754 - Bench Lille




LP754.2 - Bench Montpellier




LP755.1 - Bench Paris




LP756.1 - Bench Toulouse




LP791 - Swing-sofa Boston































LP792 - Swing-sofa Dallas



LP793 - Swing-sofa Atlanta














| Installation scheme | |
|--|--|
| LP701.1, LP701.2  | LP702.1  |
| LP703.1  | LP704.1  |
| LP705.1  | LP705.2  |
| LP706  | LP707  |
| LP708  | LPS709  |
| LP710  | LPS721  |
| LP721.1  | LP721.1-3.3  |













| | |
|---|--|
| <p>LP722, LP722.1</p>  | <p>LP722</p>  |
| <p>LP723</p>  | <p>LP724</p>  |
| <p>LP725.1</p>  | <p>LP726.1</p>  |
| <p>LP727.1</p>  | <p>LP728.1</p>  |
| <p>LP728.1B</p>  | <p>LP729</p>  |
| <p>LP730.1</p>  | <p>LP731, LP731.1</p>  |
| <p>LP732</p>  | <p>LP733.1</p>  |













| | |
|-----------------------|----------------|
| <p>LP734, LP734.1</p> | <p>LP735</p> |
| <p>LP736.1</p> | <p>LP737.1</p> |
| <p>LP738, LP738.1</p> | <p>LP739.1</p> |
| <p>LP739.2</p> | <p>LP751.1</p> |
| <p>LP752</p> | <p>LP753</p> |
| <p>LP754</p> | <p>LP754.2</p> |
| <p>LP755.1</p> | <p>LP756.1</p> |


| LP791 | LP792 |
|-------|-------|
| | |
| LP793 | |
| | |

| Concreting zones | |
|------------------|---------|
| LP701.1, LP701.2 | LP702.1 |
| | |
| LP703.1 | LP704.1 |
| | |
| LP705.1 | LP705.2 |
| | |

| | |
|--|--|
| <p>LP706</p>  | <p>LP707</p>  |
| <p>LP708</p>  | <p>LPS709</p>  |
| <p>LP710</p>  | <p>LPS721</p>  |
| <p>LP721.1</p>  | <p>LP721.1-3.3</p>  |
| <p>LP722, LP722.1</p>  | <p>LPS722</p>  |
| <p>LP723</p>  | |


| | |
|---|--|
| <p>LP724</p>  | <p>LP725.1</p>  |
| <p>LP726.1</p>  | <p>LP727.1</p>  |
| <p>LP728.1</p>  | <p>LP728.1B</p>  |
| <p>LP729</p>  | <p>LP730.1</p>  |
| <p>LP731, LP731.1</p>  | <p>LP732</p>  |
| <p>LP733.1</p>  | <p>LP734, LP734.1</p>  |

| | |
|---|---|
| <p>LP735</p>  | <p>LP736.1</p>  |
| <p>LP737.1</p>  | <p>LP738, LP738.1</p>  |
| <p>LP739.1</p>  | <p>LP739.2</p>  |
| <p>LP751.1</p>  | <p>LP752</p>  |
| <p>LP753</p>  | <p>LP754</p>  |
| <p>LP754.2</p>  | <p>LP755.1</p>  |




Scheme of bench assembly

Additional assembly schemes for other benches, see the «Appendix»




| Pos. | Name | Weight, kg | Q-ty |
|------|-------------------|------------|------|
| 1 | Bench frame | 7 | 2 |
| 2 | Brace rod | 2 | 2 |
| 3 | Lamella | 2 | 5 |
| 4 | Connection 320 mm | | 1 |
| 5 | Plug F25 mm | | 4 |
| 6 | Washer 10 | | 4 |
| 7 | Stud M10*40 | | 4 |
| 8 | Screw 5x30 | | 15 |

Picture 1 – LP701.1 (also suitable for LP701.2, LP704.1, LP722.1, LP733.1, LP734.1, LP739.2)




| Pos. | Name | Weight, kg | Q-ty |
|------|------------------------|------------|------|
| 1 | Sidepart left | 10 | 1 |
| 2 | Sidepart right | 10 | 1 |
| 3 | Lamella | 2 | 10 |
| 4 | Connector 4x50x390 | | 1 |
| 5 | Connector 4x50x250 | | 1 |
| 6 | Connector longitudinal | | 2 |
| 7 | Stud M10x30 ISO7380 | | 4 |
| 8 | Washer 10 | | 4 |
| 9 | Screw 5x30 | | 30 |

Picture 2 – LP710 (also suitable for LP706, LP707, LP708)




| Pos. | Name | Weight, kg | Q-ty |
|------|-----------------------|------------|------|
| 1 | Rack | 8 | 2 |
| 2 | Lamella | 3 | 7 |
| 3 | Brace rod | | 2 |
| 4 | Assembly angle | | 2 |
| 5 | Flange | | 1 |
| 6 | Stud M10x25 DIN7991 | | 4 |
| 7 | Stud M8x20 ISO7380 | | 8 |
| 8 | Rivet-nut M8 (covert) | | 8 |
| 9 | Washer 8 | | 8 |
| 10 | Screw 5x30 | | 21 |

Picture 3 – LP728.1 (also suitable for LP730.1)




| Pos. | Name | Weight, kg | Q-ty |
|------|-------------------------------|------------|------|
| 1 | Rack right | 9 | 1 |
| 2 | Rack left | 9 | 1 |
| 3 | Brace rod | 2 | 2 |
| 4 | Lamella | 3 | 9 |
| 5 | Connector | | 1 |
| 6 | Flange 6x60x194 | | 1 |
| 7 | Plug 40x60 | | 2 |
| 8 | Stud M10*40 | | 4 |
| 9 | Plug F25 mm (sphere, intern.) | | 4 |
| 10 | Washer 10 | | 4 |
| 11 | Screw 5x30 | | 27 |

Picture 4 – LP729 (also suitable for LP721.1, LP731.1, LP734, LP736.1, LP737.1, LP739.1, LP751.1, LP756.1)



Picture 5 – LP752 (also suitable for LP723, LP731, LP732, LP735, LP738, LP753, LP754, LP754.2)




| Pos. | Name | Weight, kg | Q-ty |
|------|--|------------|------|
| 1 | Swing sidepart left | 41 | 1 |
| 2 | Swing sidepart right | 41 | 1 |
| 3 | Sofa-pendant | 52 | 1 |
| 4 | Lamella | 3 | 6 |
| 5 | Embedment for installation in the soil | 29 | 2 |
| 6 | Plug D90 mm | | 2 |
| 7 | Plank 520 mm | | 1 |
| 8 | Screw 5x30 | | 18 |
| 9 | Bolt M10*110 | | 2 |
| 10 | Bolt M6*20 | | 2 |
| 11 | Washer 10 | | 2 |
| 12 | Washer 10 | | 2 |
| 13 | Washer 6 | | 4 |
| 14 | Cap S19 | | 2 |
| 15 | Eyebolt nut M10x1.5 | | 2 |
| 16 | Nut M6 DIN985 | | 2 |
| 17 | Rivet 4.8x12 DIN7337 | | 4 |

Picture 6 – LP792

| Methods of installing benches | | | | | | |
|-------------------------------|-------------|-------------------------------|-------------------------------|--------------------|----------------------------------|-------------------|
| № | Item number | Name | Possible ways of installation | | | |
| | | | Into the soil (LP700.1) | Concreting (LP700) | Anchor 12,0x100 M10 (92F112A0-0) | Without fastening |
| 1 | LP701.1 | Bench Prague | + | + | + | + |
| 2 | LP701.2 | Bench Brno | + | + | + | + |
| 3 | LP702.1 | Bench Munich | + | + | + | - |
| 4 | LP703.1 | Bench Lisbon | - | + | + | - |
| 5 | LP704.1 | Bench Oslo | + | + | + | - |
| 6 | LP705.1 | Bench Dublin | + | + | + | - |
| 7 | LP705.2 | Bench Belfast | + | + | + | - |
| 8 | LP706 | Bench London | + | + | + | - |
| 9 | LP707 | Bench Warsaw | + | + | + | + |
| 10 | LP708 | Bench Naples | + | + | + | + |
| 11 | LPS709 | Table with benches Copenhagen | + | + | + | + |
| 12 | LP710 | Bench Vilnius | + | + | + | - |
| 13 | LPS721 | Table Bilbao | + | + | + | + |
| 14 | LP721.1 | Bench Bilbao | + | + | + | + |
| 15 | LP721.1-3,3 | Bench Bilbao double | + | + | + | + |
| 16 | LP722 | Bench Madrid | + | + | + | + |
| 17 | LPS722 | Table Madrid | + | + | + | + |
| 18 | LP722.1 | Bench Madrid | + | + | + | + |
| 19 | LP723 | Bench Valencia | + | + | + | + |
| 20 | LP724 | Bench Seville | + | + | + | + |
| 21 | LP725.1 | Bench Granada | + | + | + | + |
| 22 | LP726.1 | Bench Cadiz | + | + | + | + |
| 23 | LP727.1 | Bench Malaga | + | + | + | + |
| 24 | LP728.1 | Bench Saragosa | + | + | + | + |
| 25 | LP728.1B | Bench Salamanca | + | + | + | + |
| 26 | LP729 | Bench La Coruna | + | + | + | + |
| 27 | LP730.1 | Bench Cordoba | + | + | + | + |
| 28 | LP731 | Bench Girona | + | + | + | + |
| 29 | LP731.1 | Bench Girona | + | + | + | + |
| 30 | LP732 | Bench Vigo | + | + | + | + |
| 31 | LP733.1 | Bench Barcelona | + | + | + | + |
| 32 | LP734 | Bench Toledo | + | + | + | - |
| 33 | LP734.1 | Bench Toledo | + | + | + | - |
| 34 | LP735 | Bench Alicante | + | + | + | + |
| 35 | LP736.1 | Bench Almeria | + | + | + | + |
| 36 | LP737.1 | Bench Albacete | + | + | + | + |
| 37 | LP738 | Bench Cartagena | + | + | + | + |
| 38 | LP738.1 | Bench Cartagena | + | + | + | + |
| 39 | LP739.1 | Bench Merida | + | + | + | + |
| 40 | LP739.2 | Bench Carmonite | + | + | + | + |
| 41 | LP751.1 | Bench Monaco | + | + | + | + |
| 42 | LP752 | Bench Marseille | + | + | + | + |
| 43 | LP753 | Bench Lyon | + | + | + | + |
| 44 | LP754 | Bench Lille | + | + | + | + |
| 45 | LP754.2 | Bench Montpellier | + | + | + | + |
| 46 | LP755.1 | Bench Paris | + | + | + | + |
| 47 | LP756.1 | Bench Toulouse | + | + | + | + |
| 48 | LP791 | Swing-sofa Boston | + | - | - | - |
| 49 | LP792 | Swing-sofa Dallas | + | - | - | - |
| 50 | LP793 | Swing-sofa Atlanta | + | - | - | - |


Procedure for installing benches in the soil



Picture 8


- 1) Dig the holes to depth of ... mm;
- 2) Screw the LP700.1 to the bench;
- 3) Install;
- 4) Cover with earth and tamp it down.

Procedure of installing benches with concreting



Picture 9


- 1) Dig the holes to depth of 300mm;
- 2) Set the embedment LP700 to the level and concrete;
- 3) Installation of the equipment should be carried out in 28 days (after the concrete has completely hardened in accordance with SBC).




Picture 10

- 1) Prepare flat concrete surface;
- 2) Mark the holes according to the holes on the bench frame and make the appropriate holes in the base to the depth required to install the anchor;
- 3) Securely fasten with anchors.


Appendix




Picture 1 – LP701.1



Picture 2 – LP701.2




Picture 3 – LP702.1




A



A-A



Б-Б (1 : 5)




B (1 : 5)




| Pos. | Name | Weight, kg | Q-ty |
|------|------------|------------|------|
| 1 | Basis | 30 | 1 |
| 2 | Lamella | 2 | 6 |
| 3 | Screw 5x30 | | 18 |


Picture 4 – LP703.1




Picture 5 – LP704.1




Picture 6 – LP705.1




Picture 7 – LP705.2




Picture 8 – LP706




Picture 9 – LP707




Picture 10 – LP708




Picture 12 – LP721.1




Picture 13 – LP721.1 – 3,3




Picture 14 – LP722




Picture 15 – LP722.1




Picture 16 – LP723




Picture 17 – LP724








Picture 18 – LP725.1




Picture 19 – LP726.1




Picture 20 – LP727.1




Б (1 : 2)



Б (1 : 3)




Г-Г (1 : 5)




| Pos. | Name | Weight, kg | Q-ty |
|------|-----------------------|------------|------|
| 1 | Rack | 8 | 2 |
| 2 | Lamella | 3 | 7 |
| 3 | Brace rod | 2 | 2 |
| 4 | Assembly angle | | 2 |
| 5 | Flange | | 1 |
| 6 | Stud M10x25 DIN7991 | | 4 |
| 7 | Stud M8x20 ISO7380 | | 8 |
| 8 | Rivet-nut M8 (covert) | | 8 |
| 9 | Washer 8 | | 8 |
| 10 | Screw 5x30 | | 21 |


Picture 21 – LP728.1







Picture 22 – LP728.1B




Picture 23 – LP729




Picture 24 – LP730.1




Picture 25 – LP731




Picture 26 – LP731.1




Picture 27 – LP732




Picture 28 – LP733.1




Picture 30 – LP734.1




Picture 31 – LP735





Picture 32 – LP736.1






Picture 33 – LP737.1



A (1 : 2)





B (1 : 2)




| Pos. | Name | Weight, kg | Q-ty |
|------|---------------------|------------|------|
| 1 | Rack left | 6 | 1 |
| 2 | Rack right | 6 | 1 |
| 3 | Brace rod | 2 | 2 |
| 4 | Lamella | 3 | 10 |
| 5 | Connector | 1 | 1 |
| 6 | Connector | | 1 |
| 7 | Stud M10*25 ISO7380 | | 4 |
| 8 | Washer 10 | | 4 |
| 9 | Screw 5x30 | | 36 |



Picture 34 – LP738



A (1 : 2)




Б (1 : 2)




| Pos. | Name | Weight, kg | Q-ty |
|------|---------------------|------------|------|
| 1 | Rack left | 8 | 1 |
| 2 | Rack right | 8 | 1 |
| 3 | Brace rod | 2 | 2 |
| 4 | Lamella | 3 | 6 |
| 5 | Connector | 1 | 1 |
| 6 | Stud M10*45 ISO7380 | | 4 |
| 7 | Washer 10 | | 4 |
| 8 | Screw 5x30 | | 24 |




Picture 35 – LP738.1



Picture 36 – LP739.1




Picture 37 – LP739.2




A (1 : 1.5)


| Pos. | Name | Weight, kg | Q-ty |
|------|-------------------------------|------------|------|
| 1 | Sidepart | 12 | 2 |
| 2 | Brace rod | 2 | 2 |
| 3 | Lamella | 3 | 3 |
| 4 | Lamella | 5 | 2 |
| 5 | Bar | 1 | 1 |
| 6 | Plug F25 mm (sphere, intern.) | | 4 |
| 7 | Stud M10*40 | | 4 |
| 8 | Washer 10 | | 4 |
| 9 | Screw 5x30 | | 21 |




Picture 38 – LP751.1






Picture 39 – LP752




A (1 : 1.5)



B (1 : 1.5)





B (1 : 1.5)




| Pos. | Name | Weight, kg | Q-ty |
|------|-------------------------------|------------|------|
| 1 | Brace rod | 2 | 2 |
| 2 | Sidepart left | 21 | 1 |
| 3 | Sidepart right | 21 | 1 |
| 4 | Lamella | 3 | 12 |
| 5 | Connector | 2 | 1 |
| 6 | Plug F25 mm (sphere, intern.) | | 4 |
| 7 | Stud M10*40 | | 4 |
| 8 | Washer 10 | | 4 |
| 9 | Screw 5x30 | | 36 |


Picture 40 – LP753




A (1 : 2)



Б (1 : 2)




В (1 : 2)




| Pos. | Name | Weight, kg | Q-ty |
|------|-------------------------------|------------|------|
| 1 | Brace rod | 2 | 2 |
| 2 | Sidepart left | 16 | 1 |
| 3 | Sidepart right | 16 | 1 |
| 4 | Lamella | 3 | 8 |
| 5 | Lamella | 5 | 2 |
| 6 | Connector | 1 | 1 |
| 7 | Bar | 1 | 1 |
| 8 | Plug F25 mm (sphere, intern.) | | 4 |
| 9 | Stud M10*40 | | 4 |
| 10 | Washer 10 | | 4 |
| 11 | Screw 5x30 | | 36 |


Picture 41 – LP754






A (1 : 1.5)



Б (1 : 1.5)




Б (1 : 1.5)




| Pos. | Name | Weight, kg | Q-ty |
|------|-------------------------------|------------|------|
| 1 | Brace rod | 2 | 2 |
| 2 | Sidepart left | 16 | 1 |
| 3 | Sidepart right | 16 | 1 |
| 4 | Lamella | 3 | 12 |
| 5 | Connector | 2 | 1 |
| 6 | Plug F25 mm (sphere, intern.) | | 4 |
| 7 | Stud M10*40 | | 4 |
| 8 | Washer 10 | | 4 |
| 9 | Screw 5x30 | | 36 |



Picture 42 – LP754.2



Picture 43 – LP755.1




Picture 44 – LP756.1







| Pos. | Name | Weight, kg | Q-ty |
|------|------------------------------------|------------|------|
| 1 | Embedment for installation in soil | 30 | 2 |
| 2 | Swing sidepart | 44 | 2 |
| 3 | Crossbar | 20 | 2 |
| 4 | Suspension Sofa | 53 | 1 |
| 5 | Lamella | 3 | 7 |
| 6 | Plank of lamellas | | 1 |
| 7 | Bracket | | 2 |
| 8 | Cap 19 f | | 8 |
| 9 | Cap 17 f | | 12 |
| 10 | Cap S19 | | 8 |
| 11 | Cap S17 | | 4 |
| 12 | Bolt M12*110 | | 8 |
| 13 | Stud-circle M10x100 | | 8 |
| 14 | Nut M10 DIN985 | | 12 |
| 15 | Nut M12 DIN985 | | 8 |
| 16 | Washer 10 | | 12 |
| 17 | Washer 12 | | 16 |
| 18 | Screw 5x30 | | 21 |
| 19 | Washer 10 | | 8 |
| 20 | Bolt M10*100 | | 4 |

Picture 45 – LP791



Picture 46 – LP792



| Pos. | Name | Weight, kg | Q-ty |
|------|------------------------------------|------------|------|
| 1 | Embedment for installation in soil | 29 | 2 |
| 2 | Sidepart | 45 | 2 |
| 3 | Crossbar | 42 | 1 |
| 4 | Suspension Sofa assembly | 51 | 1 |
| 5 | Cap 17 f | | 16 |
| 6 | Cap S19 | | 4 |
| 7 | Bolt M10*30 | | 4 |
| 8 | Stud M12x30 ISO 7380 | | 16 |
| 9 | Nut M12 DIN985 | | 16 |
| 10 | Eyebolt nut M10x1.5 | | 4 |
| 11 | Washer 10 | | 4 |
| 12 | Washer 10 | | 4 |
| 13 | Washer 12 | | 32 |

Picture 47 – LP793